

# Tinley Diverse LA3 NMEA connection to TackTick Wireless Interface

LA3 special Tacktick software version 1.02T

## CALIBRATION

(Remove load from pin before calibration)

1. With Cal Switch DOWN, set calibration voltage to zero
2. With Cal Switch UP, set CAL VOLTAGE to agree with certificate
3. Send CAL figure via a PC terminal program in the following format:  
\$PTINC,xxxx<CR><LF> where xxxx is cal figure X100
4. Return Cal Switch DOWN for normal function

